



# Corner tape Tuff-Tape TT red 30m



Manufacturer	
Dimension	0,41 x 57 mm x 30 m
Weight	0.80 kg
Product Code	TT-20
EAN	5907437026007
SKU	6904
Application	for flat joints and internal corners
IBB ID	6904

## Product specification

Manufacturer	IBB	Unit	pcs
EAN	5907437026007	Dimension	0,41 x 57 mm x 30 m

## TUFF-TAPE

Extremely durable - does not break. 0.41 mm Perfectly masks panel cracks. Easy and quick to assemble.

It has a unique structure that creates rigid and smooth surfaces.

Provides straight lines for inside corners. Water and rust resistant.

Efficient because it allows the use of 100% of the material.

Many times stronger than ordinary paper tape.

Does not require soaking in water.

Allows you to cover with any paint.

It does not require the use of additional tools, such as clips or mounting tapes.

Convenient to use, transport and store thanks to being wound on a roll.

### APPLICATION OF TUFF-TAPE:

The TUFF-TAPE tape is used for joining plasterboards on flat surfaces (such as ceilings or walls) instead of mesh, fleece, paper tape, paper tape with an aluminum insert, and for finishing internal corners. The tape is excellent for masking cracks and scratches on ceilings and walls, as well as for repairing surfaces where the mesh or paper has deteriorated. TUFF-TAPE, due to the lack of reaction with water, is used in places exposed to moisture, where the paper tape could be damaged (e.g. in the vicinity of bathtubs and showers).

### HOW TO USE:

Cut the tape to the desired length and cut the ends at a 45 degree angle.

Apply gypsum mass (except for quick-drying gypsum, e.g. building gypsum).

Use plaster to stick the tape

place the TUFF-TAPE at the destination.

In the case of internal corners - fold the tape lengthwise (with the inscriptions inwards), then gently straighten it and stick it, pressing it to the internal corner. Adjust the tape to create a straight horn line in the crease. Remove excess plaster with a spatula, leaving no air bubbles under the tape. Cover the tape with a thin layer of gypsum mass up to 0.6 mm thick, aligning it

with the plane of the wall, leave it to dry. For internal corners - do not fill the corner with plaster after installing the tape. This will keep the horn line straight. Reapply plaster if necessary and allow to dry. Smooth out the unevenness with sandpaper with a grit of at least 180. Sand the inner line of the tape bend with the edge of the bent sandpaper. When creating a flat surface of gypsum boards in the place of their connection ending with the original chamfer, which connects with another wall at different angles, the tape used in the internal corner or external corner should be applied to the tape connecting the boards that constitute a flat surface. flat surface of plasterboards that do not have a bevel. In the place where they are connected with another wall at different angles, the tape connecting the panels constituting a flat surface should be brought to the contact point with the tape used in the internal corner or external corner. In both of the above cases, this will allow us to avoid curvature of the corneal line.\* The same applies to the MEDIUM and ORIGINAL tape.